

TRIM-TEX

DRYWALL PRODUCTS

Pullaway L Bead

Used to create a finished edge when butting drywall up to another substrate. Removable strip provides $\frac{1}{2}$ " of protection from mud and also acts as a guide for the taping knife.

Installation Instructions

Step 1: Measure and cut the bead to length. Dry fit to test proper cut.

Step 2: Spray the bead and edge of drywall with 1 coat each of Trim-Tex 847 Spray Adhesive and position the bead into place.

Step 3: Once in position, pressure the leg using a Trim-Tex installation tool or the handle of your taping knife.

Step 4: Staple the mud leg into place every 6"-8" with $\frac{1}{2}$ " staples.

Step 5: Mud as usual. Be sure to use All-Purpose or Multi-Purpose Compound. Add Mud-Max to your drywall compound for extra durability.

Step 6: Remove protective strip before sanding. Prime and paint as usual.

